

# How to update Colour Scan 2.0 with NCS 2050 COLLECTION

If you do not have the CAPSURE SYNC PROGRAMME previously installed on your computer:

## **DOWNLOAD CAPSURE SYNC FOR COLOUR SCAN 2.0:**

For PC: [Capsure Sync for PC](#)

For MAC: [Capsure Sync for MAC](#)

After installation of program is complete, choose one of the following options, depending on which issue you want solved:

My device currently has NCS 1950 Standard Colours and I wish to update to NCS 2050 Standard Colour collection:

1. Open Capsure Sync on your computer.
2. Connect your Colour Scan device to the computer with the USB cable.
3. When Capsure Sync starts and asks for confirmation of synchronization, make sure that "Last sync:" is the current date and time. Click "Sync Now".
4. Mark Synchronize chosen colour charts box then select NCS 2050 COLLECTION (only).
5. Press Synchronize
6. Confirm that NCS 1950 COLLECTION will be replaced by NCS 2050 COLLECTION, click OK.
7. Click OK on Capsure Sync program on computer when synchronization is complete.

My device currently has the NCS 2050 Collection but missing LRV values, I wish to sync my device to include the updated LRV values:

1. Open Capsure Sync on your computer.
2. Connect your Colour Scan device to the computer with the USB cable.
3. When Capsure Sync starts and asks for confirmation of synchronization, make sure that "Last sync:" is the current date and time. Click "Sync Now".
4. Click OK on Capsure Sync program on computer when synchronization is complete.

For more information, detailed product manual and quick start guide, visit [ncscolour.com](https://ncscolour.com)